

圖例	型號	尺寸規格	目錄	參考價	箱數
	鏡頭蓋	27mm、28mm、30mm、40.5mm 43mm、77mm、82mm、		100	
	鏡頭蓋	46mm、49mm、52mm、55mm		50	
	鏡頭蓋	58mm、62mm、67mm、72mm		80	
	鏡頭蓋	86mm		140	
	鏡頭蓋	49mm、52mm、55mm、58mm 內外捏、附吊繩		100	
	鏡頭蓋	62mm、67mm 內外捏、附吊繩		120	
	鏡頭蓋	37mm、72mm、77mm 內外捏、附吊繩		140	
	快門線	IN-3914 (30cm) IN-3915 (50cm)		200	
	AS-598	數位相機通用型快門線 長、短兩型		400	
	閃光燈 柔光罩	AS-6430 CANON430EX AS-6580 CANON580EX AS-6600 NIKON SB600 AS-6800 NIKON SB800		240	
	IN-1220	鬆緊型鏡頭防失帶		50	
	9520	進口拉片器		420	
	IN-4138	變換螺絲帽 (10粒入)		500	